



Milesight-Troubleshooting

How to enable Two-way Audio on NVR

	XX.9.0.12 or	Undate	2022 1 26
	above	opuate	2022.1.20
Milosiaht CMS	2.4.0.12 or	M-Sight	Android 3.1.0-r2 or above
	above	Pro	IOS 3.1.0.5-r4 or above

1. Introduction

Milesight two-way Audio enables users to talk with NVR via PC. It can help you to manage your surveillance system in a more effective and simple way. Only the NVR that supports Audio I/O interface can enable two-way Audio. Before enabling this function please make sure that the NVR is connected with a **microphone** and a **speaker**. Otherwise the NVR is unable to conduct two-way audio.

The detailed steps will be shown to help you use Two-way Audio correctly in the following.

Note: The models of NVR which support audio I/O are listed below

MS-N5008-U(P)C, MS-N5016-U(P)T, MS-N7016-U(P)H, MS-N7032-U(P)H, MS-N8032-UH, MS-N8064-UH

2. How to enable two-way audio on NVR

Web Page

(1) Click 🖳 to enable Two-way Audio.





(2) If there is only one channel playing on the live view page, you can select to talk with

local NVR or the network camera. Click beside the NVR or the corresponding camera. Once the two-way Audio is enabled successfully, both the status of the microphone in the toolbar and the two-way Audio box will change to . And your voice will be delivered via the microphone and speaker of your computer, then the two-way audio is connected successfully.





(3) For the NVR with no Audio I/O interface, even though the camera hosted on the NVR

supports Audio I/O, when you click , a message box will pop up to inform you that *This channel does not support this function.* Therefore please check if the NVR you purchased supports Audio I/O interface so that you can enjoy the innovative technology from Milesight. Similarly in case of talking to the network camera with no audio I/O interface, it

will pop up the same message box to prompt you.



(4) For multiple channels that play simultaneously, you can select a random channel on the NVR, and just click beside the NVR. When the status of the tip icon switches to , you can talk with the NVR as you will.



(5) Milesight NVR also supports two-way Audio in plugin-free mode but you have to configure **HTTPS** first. If you enable two-way Audio, it will notify that *Limited function in plugin-free mode*.



Next will introduce how to enable HTTPS.

i. Enable HTTPS.



ii. Create a Private Certificate

If HTTPS is not set before, there will be a default installed certificate. You can also recreate one by yourself. If you choose to recreate one, just choose'Create a Private Certificate' in installation type, then click on **Create**.

≠	Milesight	Network							
-		Basic	UPwP		Parata a Reference Parata	1	HTTPS	Multicest	More
Ure View		HTTPS			create a Private Certin	Rate			
5		Installation Type	Create a Private	Country					
Phytock		Create a Private Certificate	Create	Common Name	(1 = 099)	dust			
		Installed Certificate		Password		Junya.			
Relies	General Settings	Attributes		Province					
털	Network			Region					
	Holiday			Organization					
X Settings				Company					
** Senter Berne Logent	Matterior .	Corr		Emai		GAR			

Milesight

iii. Fill in the relevant parameters for the certificate, click **OK**, then you can use the recreated private certificate to enable HTTPS access.

₽	Milesight	Network							
=		Basic	UPpP				IITTPS	Mußleint.	More
Line View		WITTER	Frahle		Create a private Certificati				
9		Installation Type	Create a Private	Country	CH				
lepheck:		Create a Private Certificate	Create	Derivet of Validity	10	dava*			
28		Installed Certificate		Password	Jeffrey				
	General Settings	Attributes		Province	fujian				
<u>교</u>	Network			Region	siamen				
	Holiday			Organization	milesight				
×.				Company	[mitesight				
34				Email	jeffneychen@milesight.com				
Status Loga		Cave			ox	Cancel			
E+ Legent									

iv. Open the browser and enter https://ip, then you can access the device with HTTPS protocol. And when you use private license for HTTPS to access a web site, you will see risk warning as the following picture shows.

our co	onnection is not private
Attackers n basswords,	night be trying to steal your information from 192.168.69.111 (for example, messages, or credit cards). <u>Learn more</u>
NET::ERR_CER	T_AUTHORITY_INVALID
Q To	get Chrome's highest level of security, turn on enhanced protection

v. Just click Advanced and choose Proceed to <IP address>.



Finally, you can access the web site by HTTPS.



Then the two-way audio can be enabled in plugin-free mode with the above configuration.



Note:

1. For NVR that does not support the Audio I/O interface, it only supports to talk with camera through Web page.

2. The Two-way Audio only supports one channel talking at one time.

3. Two-way Audio and Audio function can not be used together, including Audio of Playback, but if you are using Two-way Audio on one web page, you can use Audio on another page.

4. The audio interface of NVR can only be used alone. When other devices are talking to NVR, it would indicate that the device is busy if you enable Audio or Two-way Audio of other channels at the same time.



LOCAL

As the monitor system does not have both a mic-phone and speaker, so NVR should be connected with Audio I/O equipment if you want to enable two-way audio function. In this way the Two-way Audio between NVR and a network camera can work.

Click sto enable two-way audio. But if you use a network camera with no audio I/O interface, a message box will pop up and notify you that the device does not support this function.





(2) If you select a camera with Audio I/O interface to talk with, will be shown in the top-right corner of the live view interface. You can talk with the designated camera via the audio input equipment connected with the NVR.



Note:

The NVR should have Audio I/O interface otherwise you will fail to find the entrance for two-way Audio.

Milesight



Milesight CMS

Currently Milesight CMS supports managing multiple equipment which includes NVR and network cameras. So it is available to use Two-way Audio via CMS client.

For connecting NVR via IP/domain or Milesight DDNS, the default status of Two-way Audio is disabled as below:



Click is to enable two-way Audio, then you can choose to talk with the NVR or network camera.





• For the NVR which does not support the Audio I/O interface, it will note that *The device does not support Voice Taking.*



Then you can see in the top-left of the channel interface. Furthermore, only one two-way audio can be enabled at a time. If you select NVR to talk with, then switch to a network camera. A prompt box will pop up and indicate that the original two-way audio will be disabled.



For connecting NVR via P2P connections on Milesight CMS , two-way audio is not supported with this connecting method. That's why there is no to enable two-way audio on the channel interface.

	Concerning Second Second		1 Month settimoned					Cover rea		- I HATTOOLU	
No.	IP Addre	**	Port	Туре	Status	MAC Address		firmware Version		Model	
ctivate Mor	illy Network									() Rofree	ah 🖽 (
ctivate Mos ces Added 6 No.	fly Network	10	Port	Device Name	Туре	MAC Address	Status	Łdit	Dulets	ථ Refere Enable/Diaz	ch 🗄 I
tivate Mor es Added 6 No. 1	IBy Network IB Address 192,156,7178	10	Port 80	Device Name MS-N7032-UH	Тури NVR	MAC Address TCC3160809400	Status Disconnected	tdi	Deleta	ථ Refer Enable/Disz	oh 🗐 (able
tivate Mor es Added 6 No: 1 2	89 Network 89 Address 192 1987, 178 192 1987, 206	10	Port 80 80	Device Name MS-X1032-301 MS-C5372-17FC	Type NVR Camera	MAC Address TCC2160609200 TCC2160247853	Status Disconnected Connected	Edit 2	Delete 0	O Refee Enable/Dia	sh 💼 i
ivate Mor es Added 6 No. 1 2 3	07 Address 192 Address 192 193, 178 192 196, 206 192, 193, 7180	10 × -	Port 80 80	Cinvido Name Mili N7032-LM Mili C3372-TIRC Mili C3372-TIRC	Тури NVR Сатега Сатега	MAC Address 10C2/16080920 10C51624653 10C216288568	Status Disconnected Connected Disconnected	Lds 2 2	Delete 0 0	O Refer Exability(Sin G G G G	sh 💼 i
tivate Mov es Added 6 No. 1 2 3 4	19 Address 19 Address 192.168.7.178 192.168.7.00 192.169.7.100 192.169.7.105	10 	Port 80 80 80	Checko Nama MS-KY022-6H MS-C332-6HC MS-C338-5X021V/FC MS-C293-98	Type NVR Canves Canves Canves	MAC Address TCC/16080900 TCC21624653 TCC31624659 TCC31624562	Status Disconected Connected Disconected Connected	Lde L L	Dates 0 0 0	Ö Refere EnableyClu Ge Ge Ge	sh 💼 i able
tionte Moo es Added 6 No. 1 2 3 4 5	19 Vetweek 19 Vetweek 19 2 1467, 778 19 2 1467, 708 19 2 1467, 708 19 2 1467, 78	10 	Port 80 80 80 80 80	Cension Names Mis A07032-244 Mis-C5372-47RC Mis-C2936-3027UVPC Mis-C293-368 POWT89.168/279	Type NVR Cames Cames Cames Cames NVR	MAC Address TCC/160809200 TCC31624/8531 TCC31624/8531 TCC31624/824762 TCC316040560	Status Disconnetted Disconnetted Disconnetted Connested	Lds 1. 1. 1. 1. 1. 1. 1. 1. 1. 1.	Delete B B B B	ی Refere Tanthiy Glu این این این این این	sh 💼 i able



Milesight

M-sight Pro

In order to enable users to make full use of Milesight products more conveniently, M-sight Pro supports two-way audio which allows users to talk with the NVR in any place with the Internet. Generally you can talk with the device which is connected via random connection method as long as the device supports audio I/O.



If both the NVR and network camera support Audio I/O interface, after tapping gyou can select to talk with NVR or the network camera.





Note: If the NVR does not support Audio I/O interface, even the camera managed by the NVR supports two-way audio, the is unfeasible. Tapping the icon will get no feedback from M-Sight Pro.

-END-